

Installation Guide: 700 Series LED Scenelight

51 Winthrop Road,

Chester, Connecticut 06412-0684

Phone: (860) 526-9504

Internet: www.whelen.com

Sales e-mail: autosale@whelen.com

Customer Service e-mail: custserv@whelen.com

MARNING: This product can expose you to chemicals including Methylene Chloride which is known to the State of California to cause cancer, and Bisphenol A, which is known to the State of California to cause birth defects or other reproductive harm. For more information go to www.P65Warnings.ca.gov.

## Mounting:

IMPORTANT! When selecting a mounting location, keep in mind that there must be a minimum of 2" clearance around the perimeter of the lighthead and any vehicle components (insulation, etc.). The rear of the lighthead must have a minimum 1/8" clearance. This increases airflow over the heatsink and helps maintain proper operating temperature.

Caution: Permanent mounting of this product will require drilling. It is absolutely necessary to make sure that no other vehicle components could be damaged by this process. Check both sides of the mounting surface before starting. If damage is likely, select a different mounting location.

- Using the mounting diagram, mark off the mounting holes and the "cut-out" area.
- Using a 1/4" drill bit, drill the mounting holes then carefully cut and remove the area of the mounting surface indicated. Do not remove the mounting surface where the mounting holes are drilled.
  NOTE" The word "TOP" embossed on the lens must be on the

 Route the cable through the wiring hole and refer to "wiring information" for connections and fusing. After testing the operation, position the lighthead onto the mounting surface and secure to the vehicle using the four #6 x 1½" sheet metal screws and flange grommet provided.

WARNING! All customer supplied wires that connect to the positive (+) terminal of the battery must be sized to supply at least 125% of the maximum operating current and FUSED "at the battery" to carry that load. DO NOT USE CIRCUIT BREAKERS WITH THIS PRODUCT!

IMPORTANT! It is the responsibility of the installation technician to make sure that the installation and operation of this product will not interfere with or compromise the operation or efficiency of any vehicle equipment!

IMPORTANT! Before returning the vehicle to active service, visually confirm the proper operation of this product, as well as all vehicle components/equipment.

## **IMPORTANT WARNING!**

CAUTION! DO NOT LOOK DIRECTLY AT THESE LEDS WHILE THEY ARE ON. MOMENTARY BLINDNESS AND/OR EYE DAMAGE COULD RESULT!

©2008 Whelen Engineering Company Inc. Form No.14172B (121511)

top of the light after mounting.

For warranty information regarding this product, visit www.whelen.com/warranty



Installation Guide: 700 Series LED Scenelight

51 Winthrop Road, Chester, Connecticut 06412-0684

Phone: (860) 526-9504

Internet: www.whelen.com

Sales e-mail: autosale@whelen.com

Customer Service e-mail: custserv@whelen.com

MARNING: This product can expose you to chemicals including Methylene Chloride which is known to the State of California to cause cancer, and Bisphenol A, which is known to the State of California to cause birth defects or other reproductive harm. For more information go to www.P65Warnings.ca.gov.

## Mounting:

IMPORTANT! When selecting a mounting location, keep in mind that there must be a minimum of 2" clearance around the perimeter of the lighthead and any vehicle components (insulation, etc.). The rear of the lighthead must have a minimum 1/8" clearance. This increases airflow over the heatsink and helps maintain proper operating temperature.

Caution: Permanent mounting of this product will require drilling. It is absolutely necessary to make sure that no other vehicle components could be damaged by this process. Check both sides of the mounting surface before starting. If damage is likely, select a different mounting location.

- Using the mounting diagram, mark off the mounting holes and the "cut-out" area.
- Using a 1/4" drill bit, drill the mounting holes then carefully cut and remove the area of the mounting surface indicated. Do not remove the mounting surface where the mounting holes are drilled.
  - NOTE" The word "TOP" embossed on the lens must be on the top of the light after mounting.

 Route the cable through the wiring hole and refer to "wiring information" for connections and fusing. After testing the operation, position the lighthead onto the mounting surface and secure to the vehicle using the four #6 x 1½" sheet metal screws and flange grommet provided.

WARNING! All customer supplied wires that connect to the positive (+) terminal of the battery must be sized to supply at least 125% of the maximum operating current and FUSED "at the battery" to carry that load. DO NOT USE CIRCUIT BREAKERS WITH THIS PRODUCT!

IMPORTANT! It is the responsibility of the installation technician to make sure that the installation and operation of this product will not interfere with or compromise the operation or efficiency of any vehicle equipment!

IMPORTANT! Before returning the vehicle to active service, visually confirm the proper operation of this product, as well as all vehicle components/equipment.

## **IMPORTANT WARNING!**

CAUTION! DO NOT LOOK DIRECTLY AT THESE LEDS WHILE THEY ARE ON. MOMENTARY BLINDNESS AND/OR EYE DAMAGE COULD RESULT!



