


PHAZER / LCS771

Quick-Install Guide



<u>SLIDE SWITCH</u>	<u>POSITION</u>	<u>FUNCTION</u>	<u>ROCKER SWITCH</u>	<u>FUNCTION</u>
	1	Priority 1	SW1	Scene Lighting
	2	Priority 2	SW2	Left Alley
	3	Priority 3	SW3	Right Alley
			SW4	TD Warn
			SW5	TD Left
			SW6	TD Right
			SW5 & SW6	TD Center Out

QUICK INSTALLATION CHECKLIST

- 8 AWG Wire to Ground Terminal
- +12VDC Power Connections (Use 14 AWG):
 - ▲ All three Light Power Terminals
 - ▲ 6 Red wires
 - ▲ Terminal 11 of 12-Way Connector (for backlighting)
 - ▲ Ignition Switched to Terminals 1 & 2 of 12-Way Connector
- Lights connected to SW1-SW6 outputs
- Speaker (+) and (-) connected
- Correct AUX and Park-Kill polarity (+ is default)
- PA/VOL turned ON

Electrical Connections

